Exclusive Garden
OUTDOOR LIVING

Top	Leg	Table	Name
SC/372	SC/543	FC/348	RICHMOND
SC/375	SC/543	FM/109	DARWIN
SC/376	SC/543	FM/132	TOBARRA

PLEASE ASSEMBLE ON A SOFT SURFACE TO AVOID DAMAGING TABLETOP

Step 1: Assemble ring to legs. Step 2: Attach leg assembly to tray. Step 3: Bolt frame to tabletop, tighten all bolts once whole table is assembled.

PROTECT TABLETOP FROM FROST, for full care instructions visit www.europaleisure.co.uk

In the event of difficulty, please call Consumer Services on 01722 742763

Europa Leisure

Assembly Instructions

Ref	Description	Picture	Qty
A	Table Leg A		1
B	Table Leg B		1
C	Top		1

Ref	Description	Picture	Qty
D	Head Bolt (M6*14)		8
E	Hex Wrench (4MM)		1
F			

Ref	Description	Picture	Qty
G			
H			
I			





Do not tighten any of the bolts until the table is completely assembled