Exclusive Garden
OUTDOOR LIVING

Code	Name	Table Top	Table Leg
		Part No.	Part No.
FC-227	CARMONA 76cm Table	SC/227	SC/543
FC-247	PINAROSA 76cm Table	SC/247	SC/543
FC-348	RICHMOND 76cm Table	SC/348	SC/543
FC-367	RONDARA 76cm Table	SC/367	SC/543

Assembly Instructions

PLEASE ASSEMBLE ON A SOFT SURFACE TO AVOID DAMAGING THE TABLETOP
Join the 2 leg sections and loosely attach to the tabletop.
Once all the screws are loosely inserted they can be fully tightened.

It may be necessary to exert a little pressure, and possibly twist a leg slightly,
to get the holes on the leg plates to align with the threaded holes in the table top.

PROTECT TABLETOP FROM FROST, for full care instructions visit www.europaleisure.co.uk

In the event of difficulty, please call Consumer Services on 01722 742763

Europa Leisure

Assembly Instructions

Ref	Description	Picture	Qty
A	Table Leg A		1
B	**Table Leg B**		1
C	Top		1

Ref	Description	Picture	Qty
D	**Head Bolt (M6*14)**		8
E	Hex Wrench (4MM)		1
F			

Ref	Description	Picture	Qty
G			
H			
I			





Do not tighten any of the bolts until the table is completely assembled